

205-345

RC4200

RC4200

Analog Multiplier

Description

The RC4200 analog multiplier has complete compensation for nonlinearity, the primary source of error and distortion. This multiplier also has three on-board operational amplifiers designed specifically for use in multiplier logging circuits. These amplifiers are frequency compensated for optimum AC response in a logging circuit, the heart of a multiplier, and can therefore provide superior AC response.

The RC4200 can be used in a wide variety of applications without sacrificing accuracy. Four-quadrant multiplication, two-quadrant division, square rooting, squaring and RMS conversion can all be easily implemented with predictable accuracy. The nonlinearity compensation is not just trimmed at a single temperature, it is designed to provide compensation over the full temperature range. This nonlinearity compensation combined with the low gain and offset drift inherent in a well-designed monolithic chip provides a very high accuracy and a low temperature coefficient.

The excellent linearity and versatility were achieved through circuit design rather than special grading or trimming, and therefore, unit cost is very low.

The RC4200 is ideal for use in low distortion audio modulation circuits, voltage-controlled active filters, and precision oscillators.

Features

- ◆ High accuracy
Nonlinearity — 0.1%
Temperature coefficient — 0.005%/°C
- ◆ Multiple functions
Multiply, divide, square, square root, RMS-to-DC conversion, AGC and modulate/demodulate
- ◆ Wide bandwidth — 4 MHz
- ◆ Signal-to-noise ratio — 94 dB

RC4200

Absolute Maximum Ratings

Supply Voltage ¹	-22V
Internal Power Dissipation ²	500 mW
Input Current	-5 mA
Storage Temperature Range	
RM4200/4200A	-65°C to +150°C
RC4200/4200A	-55°C to +125°C
Operating Temperature Range	
RM4200/4200A	-55°C to +125°C
RC4200/4200A	0°C to +70°C

Notes:

1. For a supply voltage greater than -22V, the absolute maximum input voltage is equal to the supply voltage.
2. Observe package thermal characteristics.

Ordering Information

Part Number	Package	Operating Temperature Range
RC4200N	N	0°C to +70°C
RC4200AN	N	0°C to +70°C
RM4200D	D	-55°C to +125°C
RM4200AD	D	-55°C to +125°C
RM4200AD/883B	D	-55°C to +125°C

Notes:

/883B suffix denotes MIL-STD-883, Level B processing
 N = 8-lead plastic DIP
 D = 8-lead ceramic DIP

Connection Information

Top View		Pin	Function
1	O	1	I ₂
2		2	V _{OS2}
3		3	-V _S
4		4	I ₃ (Output)
5		5	I ₄
6		6	GND
7		7	V _{OS1}
8		8	I ₁

65-0070

Thermal Characteristics

(Still air, soldered into PC board)

	8-Lead Plastic DIP	8-Lead Ceramic DIP
Max. Junction Temp.	+125°C	+175°C
Max. P _D T _A < 50°C	468 mW	833 mW
Therm. Res. θ _{JC}	—	45°C/W
Therm. Res. θ _{JA}	160°C/W	150°C/W
For T _A > 50°C Derate at	6.25 mW/°C	8.33 mW/°C

Electrical Characteristics(Over operating temperature range, $V_s = -15V$ unless otherwise noted)

Parameters	Test Conditions	4200A			4200			Units
		Min	Typ	Max	Min	Typ	Max	
Total Error as Multiplier Untrimmed With External Trim Versus Temperature Versus Supply (-9 to -18V)	$T_A = +25^\circ C$ Note 1		± 2.0 ± 0.2 ± 0.005 ± 0.1			± 0.2 ± 0.005 ± 0.1	± 3.0 ± 0.2 ± 0.005 ± 0.1	% % %/°C %/V
Nonlinearity	$50 \mu A \leq I_{1,2,4} \leq 250 \mu A$, $T_A = +25^\circ C$ (Note 2)			± 0.1			± 0.3	%
Input Current Range (I_1 , I_2 and I_4)		1.0		1000	1.0		1000	μA
Input Offset Voltage	$I_1 = I_2 = I_4 = 150 \mu A$ $T_A = +25^\circ C$			± 5.0			± 10	mV
Input Bias Current	$I_1 = I_2 = I_4 = 150 \mu A$ $T_A = +25^\circ C$			300			500	nA
Average Input Offset Voltage Drift	$I_1 = I_2 = I_4 = 150 \mu A$			± 50			± 100	$\mu V/^\circ C$
Output Current Range (I_3)	Note 3	1.0		1000	1.0		1000	μA
Frequency Response, -3dB point Supply Voltage		-18	4.0 -15	-9.0	-18 -15	4.0 -9.0	MHz V	
Supply Current	$I_1 = I_2 = I_4 = 150 \mu A$ $T_A = +25^\circ C$			4.0			4.0	mA

Notes:

1. Refer to Figure 6 for example.
2. The input circuits tend to become unstable at $I_1, I_2, I_4 < 50 \mu A$ and linearity decreases when $I_1, I_2, I_4 > 250 \mu A$ (eq. @ $I_1 = I_2 = 500 \mu A$, nonlinearity error ~ 0.5%).
3. These specifications apply with output (I_3) connected to an op amp summing junction. If desired, the output (I_3) at pin (4) can be used to drive a resistive load directly. The resistive load should be less than 700Ω and must be pulled up to a positive supply such that the voltage on pin (4) stays within a range of 0 to +5V.

RC4200

Functional Description

The RC4200 multiplier is designed to multiply two input currents (I_1 and I_2) and to divide by a third input current (I_4). The output is also in the form of a current (I_3). A simplified circuit diagram is shown in Figure 1. The nominal relationship between the three inputs and the output is:

$$I_3 = \frac{I_1 I_2}{I_4} \quad (1)$$

The three input currents must be positive and restricted to a range of $1 \mu\text{A}$ to 1 mA . These currents go into the multiplier chip at op amp summing junctions which are nominally at zero volts. Therefore, an input voltage can be easily converted to an input current by a series resistor. Any number of currents may be summed at the inputs. Depending on the application, the output current can be converted to a voltage by an external op amp or used directly. This capability of combining input currents and voltages in various combinations provides great versatility in application.

Inside the multiplier chip, the three op amps make the collector currents of transistors Q1, Q2 and Q4 equal to their respective input currents (I_1 , I_2 , and I_4). These op amps are designed with current-source outputs and are phase-compensated for optimum frequency response

as a multiplier. Power drain of the op amps was minimized to prevent the introduction of undesired thermal gradients on the chip. The three op amps operate on a single supply voltage (nominally -15V) and total quiescent current drain is less than 4 mA . These special op amps provide significantly improved performance in comparison to 741-type op amps.

The actual multiplication is done within the log-antilog configuration of the Q1-Q4 transistor array. These four transistors, with associated proprietary circuitry, were specially designed to precisely implement the relationship

$$V_{BEN} = \frac{KT}{Q} \ln \frac{I_{CN}}{I_{SN}} \quad (2)$$

Previous multiplier designs have suffered from an additional undesired linear term in the above equation; the collector current times the emitter resistance. The I_{CRE} term introduces a parabolic nonlinearity even with matched transistors. Raytheon has developed a unique and proprietary means of inherently compensating for this undesired I_{CRE} term. Furthermore, this Raytheon-developed circuit technique compensates linearity error over temperature changes. The nonlinearity versus temperature is significantly improved over earlier designs.

From equation (2) and by assuming equal transistor junction temperatures, summing base-to-emitter voltage drops around the transistor array yields:

$$\frac{KT}{q} \left[\ln \frac{I_1}{I_{S1}} = \ln \frac{I_2}{I_{S2}} - \ln \frac{I_3}{I_{S3}} - \ln \frac{I_4}{I_{S4}} \right] = 0 \quad (3)$$

This equation reduces to:

$$\frac{I_1 I_2}{I_3 I_4} = \frac{I_{S1} I_{S2}}{I_{S3} I_{S4}} \quad (4)$$

The ratio of reverse saturation currents, $I_{S1} I_{S2} / I_{S3} I_{S4}$, depends on the transistor matching. In a monolithic multiplier this matching is easily achieved and the ratio is very close to unity, typically $1.0 \pm 1\%$. The final result is the desired relationship:

$$I_3 = \frac{I_1 I_2}{I_4} \quad (5)$$

The inherent linearity and gain stability combined with low cost and versatility makes this new circuit ideal for a wide range of nonlinear functions.




Figure 1. Functional Diagram

RC4200

Extended Range

The input and output voltage ranges can be extended to include 0 and negative voltage signals by adding bias currents. The $R_S C_S$ filter circuits are eliminated when the input and biasing resistors are selected to limit the respective currents to 50 μA min. and 250 μA max.

Extended Range Multiplier




Figure 5

65-1881

Resistors R_a and R_b extend the range of the V_x and V_y inputs by picking values such that:

$$I_1(\text{min.}) = \frac{V_x(\text{min.})}{R_1} + \frac{V_{\text{REF}}}{R_a} = 50 \mu A,$$

$$\text{and } I_1(\text{max.}) = \frac{V_x(\text{max.})}{R_1} + \frac{V_{\text{REF}}}{R_a} = 250 \mu A;$$

$$\text{also } I_2(\text{min.}) = \frac{V_y(\text{min.})}{R_2} + \frac{V_{\text{REF}}}{R_b} = 50 \mu A,$$

$$\text{and } I_2(\text{max.}) = \frac{V_y(\text{max.})}{R_2} + \frac{V_{\text{REF}}}{R_b} = 250 \mu A.$$

Resistor R_c supplies bias current for I_3 which allows the output to go negative.

Resistors R_{Cx} and R_{Cy} permit equation (6) to balance, i.e.:

$$\left(\frac{V_x}{R_1} + \frac{V_{\text{REF}}}{R_a} \right) + \left(\frac{V_y}{R_2} + \frac{V_{\text{REF}}}{R_b} \right) = \left(\frac{V_0}{R_0} + \frac{V_{\text{REF}}}{R_c} + \frac{V_x}{R_{Cx}} + \frac{V_y}{R_{Cy}} \right) \left(\frac{V_{\text{REF}}}{R_d} \right)$$

$$\frac{V_y V_x}{R_1 R_2} + \frac{V_x V_{\text{REF}}}{R_1 R_b} + \frac{V_y V_{\text{REF}}}{R_2 R_a} + \frac{V_{\text{REF}}^2}{R_a R_b} =$$

$$\frac{V_0 V_{\text{REF}}}{R_0 R_d} + \frac{V_x V_{\text{REF}}}{R_{Cx} R_d} + \frac{V_y V_{\text{REF}}}{R_{Cy} R_d} + \frac{V_{\text{REF}}^2}{R_c R_d}$$

Cross-Product Cancellation

Cross-products are a result of the $V_x V_R$ and $V_y V_R$ terms. To the extent that: $R_1 R_b = R_{Cx} R_d$ and $R_2 R_a = R_{Cy} R_d$, cross-product cancellation will occur.

Arithmetic Offset Cancellation

The offset caused by the V_{REF}^2 term will cancel to the extent that: $R_a R_b = R_c R_d$, and the result is:

$$\frac{V_y V_x}{R_1 R_2} = \frac{V_0 V_{\text{REF}}}{R_0 R_d} \text{ or } V_0 = V_x V_y K$$

$$\text{Where } K = \frac{R_0 R_d}{V_{\text{REF}} R_1 R_2}$$

Resistor Values

Inputs:

$$V_x(\text{min.}) \leq V_x \leq V_x(\text{max.})$$

$$\Delta V_x = V_x(\text{max.}) - V_x(\text{min.})$$

$$V_y(\text{min.}) \leq V_y \leq V_y(\text{max.})$$

$$\Delta V_y = V_y(\text{max.}) - V_y(\text{min.})$$

$$V_{\text{REF}} = \text{Constant (+7V to +18V)}$$

$$K = \frac{V_0}{V_x V_y} \quad (\text{Design Requirement})$$

$$R_1 = \frac{\Delta V_x}{200 \mu A}, R_2 = \frac{\Delta V_y}{200 \mu A}, R_d = \frac{V_{\text{REF}}}{250 \mu A}$$

$$R_a = \frac{\Delta V_x V_{\text{REF}}}{250 \mu A \Delta V_x - 200 \mu A V_x(\text{max.})}$$

$$R_b = \frac{\Delta V_y V_{\text{REF}}}{250 \mu A \Delta V_y - 200 \mu A V_y(\text{max.})}$$

$$R_c = \frac{R_a R_b}{R_d}, R_{Cx} = \frac{R_1 R_b}{R_d}, R_{Cy} = \frac{R_2 R_a}{R_d}$$

$$R_0 = \frac{\Delta V_x \Delta V_y K}{160 \mu A}$$

Basic Circuits


Current Multiplier/Divider

The basic design criteria for all circuit configurations using the 4200 multiplier is contained in equation (1):

$$\text{i.e., } I_3 = \frac{I_1 I_2}{I_4}$$


The current-product-balance equation restates this as:

$$I_1 I_2 = I_3 I_4 \quad (6)$$



65-1883

Figure 2




65-1882

Amplifier A1 is used to convert the I_3 current to an output voltage.

Multiplier: $V_Z = \text{constant} \neq 0$
Divider: $V_Y = \text{constant} \neq 0$

Figure 3

Voltage Multiplier/Divider



65-1884

$$\text{Solving for } V_0 = \frac{V_x V_y}{V_z} \frac{R_0 R_4}{R_1 R_2}$$

For a multiplier circuit $V_Z = V_R = \text{constant}$

$$\text{Therefore: } V_0 = V_x V_y K \text{ where } K = \frac{R_0 R_4}{V_R R_1 R_2}$$

For a divider circuit $V_Y = V_R = \text{constant}$

$$\text{Therefore: } V_0 = \frac{V_x}{V_z} K \text{ where } K = \frac{V_R R_0 R_4}{R_1 R_2}$$

Figure 4

Multiplying Circuit Offset Adjust

$$10K \leq R_5 = R_9 = R_{16} \leq 50K$$

$$R_7 = R_{11} = R_{14} = 100\Omega$$


$$R_6 = R_{10} = 100\Omega (V_S/0.05)$$

$$R_{15} = 100\Omega (V_S/0.10)$$

$$R_8 = R_1 || R_a$$

$$R_{12} = R_2 || R_b$$

$$R_{13} = R_0 || R_C || R_{CX} || R_{CY}$$



65-1880

Procedure:

1. Set all trimmer pots to 0V on the wiper.
2. Connect V_X input to ground. Put in a full scale square wave on V_Y input. Adjust $X_{OS}(R_5)$ for no square wave on V_O output (adjust for 0 feedthrough).
3. Connect V_Y input to ground. Put in a full scale square wave on V_X input. Adjust $Y_{OS}(R_9)$ for no square wave on V_O output (adjust for 0 feedthrough).
4. Connect V_X and V_Y to ground. Adjust $V_{OS}(R_{16})$ for 0V on V_O output.

Figure 6

RC4200

Extended Range Divider




Figure 7

As with the extended range multiplier, resistors R_{az} and R_{ao} are added to cancel the cross-product error caused by the biasing resistors, i.e.,

$$\left(\frac{V_X}{R_1} + \frac{V_0}{R_{ao}} + \frac{V_Z}{R_{az}} + \frac{V_{REF}}{R_a} \right) \left(\frac{V_{REF}}{R_b} \right) = \left(\frac{V_0}{R_0} + \frac{V_{REF}}{R_c} \right) \left(\frac{V_Z}{R_4} + \frac{V_{REF}}{R_d} \right)$$

$$\frac{V_X V_{REF}}{R_1 R_b} + \frac{V_0 V_{REF}}{R_{ao} R_b} + \frac{V_Z V_{REF}}{R_{az} R_b} + \frac{V_{REF}^2}{R_a R_b} =$$

$$\frac{V_0 V_Z}{R_0 R_4} + \frac{V_0 V_{REF}}{R_0 R_d} + \frac{V_Z V_{REF}}{R_4 R_c} + \frac{V_{REF}^2}{R_c R_d}$$

To cancel cross-product and arithmetic offset:

$$R_{ao}R_b = R_0R_d, R_{az}R_b = R_4R_c \text{ and } R_aR_h = R_cR_d$$

and the result is:

$$\frac{V_X V_{REF}}{R_1 R_b} = \frac{V_0 V_z}{R_0 R_4} \quad \text{or} \quad V_0 = \frac{V_X}{V_z K}$$

$$\text{where } K = \frac{V_{REF} R_0 R_4}{R_1 R_b}$$

Note: it is necessary to match the above resistor cross products to within the amount of error tolerable in the output offset, i.e., with a 10V F.S. output, 0.1% resistor cross-product match will give $0.1\% \times 10V = 10\text{ mV}$ untrimmable output offset voltage.

Resistor Values

Inputs:

$$V_X(\min.) \leq V_X \leq V_X(\max.)$$

$$\Delta V_x = V_x(\text{max.}) - V_x(\text{min.})$$

$$V_Z(\text{min.}) \leq V_Z \leq V_Z(\text{max.})$$

$$\Delta V_7 = V_7(\text{max.}) - V_7(\text{min.})$$

$V_{REF} = \text{Constant (+7V to +18V)}$

Outputs:

$$V_0(\min.) \leq V_0 \leq V_0(\max.)$$

$$\Delta V_0 = V_0(\text{max.}) - V_0(\text{min.})$$

$$K = \frac{V_0 V_Z}{V_x} \text{ (Design Requirement)}$$

$$R_0 = \frac{\Delta V_0}{750 \mu A} , R_b = \frac{V_{REF}}{250 \mu A} , R_4 = \frac{\Delta V_Z}{200 \mu A}$$

$$R_C = \frac{\Delta V_0 V_{REF}}{750 \mu A \Delta V_0 - 700 \mu A V_0(\text{max.})}$$

$$R_d = \frac{\Delta V_Z V_{REF}}{250 \mu A \Delta V_Z - 200 \mu A V_Z(\text{max.})}$$

$$R_a = \frac{R_c R_d}{R_b}, \quad R_{az} = \frac{R_c R_4}{R_b}, \quad R_{ao} = \frac{R_0 R_d}{R_b}$$

$$R_1 = \frac{\Delta V_0 \Delta V_Z}{600 \text{ nA} K}$$

Extended Range Circuit Errors

The extended range configurations have a disadvantage in that additional accuracy errors may be introduced by resistor product mismatching.

Multiplier (Figure 6)

An error in resistor product matching will cause an equivalent feedthrough or output offset error:

1. $R_1 R_b = R_{CX} R_d \pm \alpha$, V_X feedthrough ($V_Y = 0$) = $\pm \alpha V_X$
2. $R_2 R_a = R_{CY} R_d \pm \beta$, V_Y feedthrough ($V_X = 0$) = $\pm \beta V_Y$
3. $R_a R_b = R_{CR} R_d \pm \gamma$, V_0 offset ($V_X = V_Y = 0$) = $\pm \gamma V_{REF}$

*Output offset errors can always be trimmed out with the output op amp offset adjust, V_{OS} (R_{16}).

Reducing Mismatch Errors (Figure 6)

You need not use .01% resistors to reduce resistor product mismatch errors. Here are a couple of ways to squeeze maximum accuracy out of the extended range multiplier (see Figure 6) using 1% resistors.

Method #1

V_X feedthrough, for example, occurs when $V_Y = 0$ and $V_{OSY} \neq 0$. This V_X feedthrough will equal $\pm V_X V_{OSY}$. Also, if $V_{OSZ} \neq 0$, there is a V_X feedthrough equal to $\pm V_X V_{OSZ}$. A resistor-product error of α will cause a V_X feedthrough of $\pm \alpha V_X$. Likewise, V_Y feedthrough errors are: $\pm V_Y V_{OSX}$, $\pm V_Y V_{OSZ}$ and $\pm \beta V_Y$.

Total feedthrough:

$$\pm V_X V_{OSY} \pm V_Y V_{OSX} \pm \alpha V_X \pm \beta V_Y \pm (V_X + V_Y) V_{OSZ}$$

By carefully adjusting $X_{OS}(R_5)$, $Y_{OS}(R_9)$ and $Z_{OS}(R_{20})$ this equation can be made to very nearly equal zero and the feedthrough error will practically disappear.

A residual offset will probably remain which can be trimmed out with $V_{OS}(R_{16})$ at the output of amp.

Method #2

Notice that the ratios of $R_1 R_b : R_{CX} R_d$ and $R_2 R_a : R_{CY} R_d$ are both dependent of R_d , also that R_1 , R_2 , R_a and R_b are all functions of the maximum input requirements. By designing a multiplier for the same input ranges on both V_X and V_Y then $R_1 = R_2$, $R_{CX} = R_{CY}$ and $R_a = R_b$. (Note: It is acceptable to design a four quadrant multiplier and use only two quadrants of it.)

Select R_d to be 1% or 2% below (or above) the calculated value. This will cause α and β to both be positive (or negative) by nearly the same amount. Now the effective value of R_d can be trimmed with an offset adjustment $Z_{OS}(R_{20})$ on pin 5.

This technique will cause: 1) a slight gain error which can be compensated for with the R_0 value, and 2) an output offset error that can be trimmed out with $V_{OS}(R_{16})$ on the output op amp.

Extended Range Divider (Figure 8)

The only cross-product error of interest is the V_Z feedthrough ($V_X = 0$ and $V_{OSX} \neq 0$) which is easily adjusted with $X_{OS}(R_5)$.

Resistor product mismatch will cause scaling errors (gain) that could be a problem for very low values of V_Z . Adjustments to $Y_{OS}(R_{18})$ can be made to improve the high gain accuracy.

Square Root and Squaring (Figures 10 and 12)

These circuits are functions of single variables so feedthrough, as such, is not a consideration. Cross product errors will effect incremental accuracy that can be corrected with $Y_{OS}(R_{14})$ or $Z_{OS}(R_{10})$.

RC4200

Appendix 2 — Applications

Design Considerations for RMS-to-DC Circuits


Average Value

Consider $V_{IN} = A \sin \omega t$. By definition,

$$V_{AG} = \frac{2}{T} \int_0^{\frac{T}{2}} V_{IN} dt$$

Where T = Period

$$\begin{aligned}\omega &= 2\pi f \\ &= \frac{2\pi}{T}\end{aligned}$$



65-1873

$$\begin{aligned}V_{AG} &= \frac{2}{T} \int_0^{\frac{T}{2}} A \sin \omega t dt \\ &= \frac{2A}{T} \left[-\frac{1}{\omega} \cos \omega t \right]_0^{\frac{T}{2}} \\ &= \frac{2A}{2\pi} [-\cos(\pi) + \cos(0)]\end{aligned}$$

Average Value of $A \sin \omega t$ is $\frac{2}{\pi} A$

therefore, the rms value of $A \sin \omega t$ becomes:

$$V_{rms} = \frac{A}{\sqrt{2}}$$

RMS Value for Rectified Sine Wave

Consider $V_{IN} = |A \sin \omega t|$, a rectified wave. To solve, integrate of each half cycle.


$$\text{i.e. } \frac{1}{T} \int_0^T V_{IN}^2 dt =$$

$$\frac{1}{T} \left[\int_0^{\frac{T}{2}} A^2 \sin^2 \omega t dt + \int_{\frac{T}{2}}^T (-A \sin \omega t)^2 dt \right]$$


This is the same as $\frac{1}{1} \int_0^T A^2 \sin^2 \omega t dt$

so, $|A \sin \omega t|_{rms} = A \sin \omega t_{rms}$

Practical Consideration: $|A \sin \omega t|$ has high-order harmonics; $A \sin \omega t$ does not. Therefore, non-ideal integrators may cause different errors for two approaches.



(a)



(b)

$$\text{Avg} \left[\frac{|V_{IN}|^2}{V_O} \right] = V_O$$

$$\text{Implies } V_O = \sqrt{\text{Avg}(|V_{IN}|^2)}$$

$$V_O = \sqrt{\text{Avg} V_{IN}^2}$$

Figure 15




Figure 16. RMS to DC Converter $V_{OUT} = \sqrt{V_{IN}^2}$

Amplitude Modulator with A.G.C. (Figure 17)

In many AC modulator applications, unwanted output modulation is caused by variations in carrier input amplitude. The versatility of the RC4200 multiplier can be utilized to eliminate this undesired fluctuation. The extended range multiplier circuit (Figure 5) shows an output amplitude inversely proportional to the reference voltage V_{REF} .

$$\text{i.e., } V_0 = \frac{V_X V_Y}{V_{REF}} \cdot \frac{R_0 R_d}{R_1 R_2}$$

By making V_{REF} proportional to V_Y (where V_Y is the carrier input) such that:

$$V_{REF} = V_H = \sqrt{|V_Y|},$$

Then the denominator becomes a variable value that automatically provides constant gain, such that the modulating input (V_X) modulates the carrier (V_Y) with a fixed scale factor even though the carrier varies in amplitude.

If V_H is made proportional to the average value of $A \sin \omega t$ (i.e., $2A/\pi$) and scaled by a value of $\pi/2$ then:

$$V_H = A$$

and if: $V_X = \text{Modulating input } (V_M)$

and: $V_Y = \text{Carrier input } (A \sin \omega t)$

$$\text{Then: } V_0 = K V_M \sin \omega t \text{ where } K = \frac{R_0 R_d}{R_1 R_2}$$

The resistor scaling is determined by the dynamic range of the carrier variation and modulating input.

The resistor values are solved, as with the other extended range circuits, in terms of the input voltages.

Input voltages:

Modulation voltage (V_M): $0 \leq V_M \leq V_X(\text{max.})$

Carrier (V_Y): $V_Y = A \sin \omega t$


Carrier amplitude fluctuation (ΔA):

$$A(\text{min.}) \sin \omega t \leq V_Y \leq A(\text{max.}) \sin \omega t$$

Dynamic Range (N): $A(\text{max.})/A(\text{min.})$,

$$A(\text{max.}) = V_H(\text{max.}) \text{ and } A(\text{min.}) = V_H(\text{min.})$$

RC4200



65-1866

Figure 17. Amplitude Modulator with A.G.C.

The maximum and minimum values for I_1 and I_2 lead to:

$$I_1(\text{max.}) = \frac{V_X(\text{max.})}{R_1} + \frac{V_H(\text{max.})}{R_a} = 250 \mu\text{A}$$

$$I_1(\text{min.}) = \frac{V_H(\text{min.})}{R_a} = 50 \mu\text{A} \quad V_M(\text{min.}) = 0$$

$$I_2(\text{max.}) = \frac{A(\text{max.})}{R_2} + \frac{V_H(\text{max.})}{R_a} = 250 \mu\text{A}$$

$$I_2(\text{min.}) = \frac{V_H(\text{min.})}{R_a} = 50 \mu\text{A}$$

For a dynamic range of N , where

$$N = \frac{A(\text{max.})}{A(\text{min.})} < 5,$$

These equations combine to yield:

$$R_1 = \frac{V_X(\text{max.})}{(5-N)50\mu\text{A}}, \quad R_2 = \frac{A(\text{max.})}{(5-N)50\mu\text{A}}$$

$$R_a = \frac{A(\text{min.})}{50\mu\text{A}} \quad \text{and} \quad R_O = K \frac{R_1 R_2}{R_a}$$

Example #1

$V_Y = A \sin \omega t \quad 2.5V \leq A \leq 10V$, therefore $N = 4$
 $0V \leq V_M \leq 10V$, therefore $V_X(\text{max.}) = 10V$
 $K = 1$, therefore $V_0 = V_M \sin \omega t$

$$R_1 = \frac{V_X(\text{max.})}{50\mu\text{A}} = \frac{10V}{50\mu\text{A}} = 200K$$

$$R_1 = \frac{A(\text{max.})}{50\mu\text{A}} = \frac{10V}{50\mu\text{A}} = 200K$$

$$R_a = \frac{A(\text{min.})}{50\mu\text{A}} = \frac{2.5V}{50\mu\text{A}} = 50K$$

$$R_O = K \frac{R_1 R_2}{R_a} = 1 \frac{200K \times 200K}{50K} = 800K$$

Example #2

$V_Y = A \sin \omega t \quad 3 \leq A \leq 6$, therefore $N = 2$
 $0V \leq V_M \leq 8V$, therefore $V_X(\text{max.}) = 8V$
 $K = .2$, therefore $V_0 = .2 V_M \sin \omega t$
so:
 $R_1 = 53.3K$, $R_2 = 40K$
 $R_a = 60K$ and $R_O = 7.11K$




Figure 18. First Quadrant Multiplier/Divider

Limited Range, First Quadrant Applications

The following circuit has the advantage that cross-product errors are due only to input offsets and nonlinearity error is slightly less for lower input currents.


The circuit also has no standby current to add to the noise content, although the signal-to-noise ratio worsens at very low input currents ($1.5 \mu\text{A}$) due to the noise current of the input stages.

The $R_S C_S$ filter circuits are added to each input to improve the stability for input currents below 50 μA .

Caution

The bandpass drops off significantly for lower currents ($<50 \mu\text{A}$) and non-symmetrical rise and fall times can cause second harmonic distortion.

Thermal Symmetry



The scale factor is sensitive to temperature gradients across the chip in the lateral direction. Where possible, the package should be oriented such that sources generating temperature gradients are located physically on the line of thermal symmetry. This will minimize scale-factor error due to thermal gradients.

RC4200









Figure 19








Figure 21. AC Feedthrough vs. Frequency

RC4200

Schematic Diagram



Square Root Circuit Offset Adjust



65-1876

$$R_7 = 100\Omega$$

$$R_6 = R_7 \frac{V_S}{0.05}$$

$$R_8 = R_1 | R_a | R_{ao}$$

$$R_9 = R_b$$

$$R_{10} = R_0 | R_c$$

$$R_{11} = 100\Omega$$

$$R_{12} = R_{11} \frac{V_S}{0.1}$$


Procedure

1. Set both trimmer pots to 0V on the wiper.
2. Put in a full scale (0 to V_X (max.) squarewave on V_X input. Adjust $X_{OS}(R_5)$ for proper peak-to-peak amplitude on V_O output. (Scaling adjust)
3. Connect V_X input to ground. Adjust $V_{OS}(R_{13})$ for 0V on V_O output.

Figure 10

RC4200

Squaring Circuits $V_0 = K V_X^2$



65-1875

$$\frac{V_X^2}{R_1^2} + \frac{2V_X V_{REF}}{R_1 R_a} + \frac{V_{REF}^2}{R_a^2} = \frac{V_0 V_{REF}}{R_0 R_d} + \frac{V_{REF}^2}{R_c R_d} + \frac{V_X V_{REF}}{R_c R_d}$$

If $R_a^2 = R_c R_d$ and $R_1 R_a = 2R_{cx} R_d$

$$\text{then } \frac{V_0 V_{REF}}{R_0 R_d} = \frac{V_X^2}{R_1^2} \text{ or } V_0 = KV_X^2 \text{ where } K = \frac{R_0 R_d}{V_{REF} R_1^2}$$

$$V_X(\text{min.}) \leq V_X \leq V_X(\text{max.}) \quad \Delta V_X = V_X(\text{max.}) - V_X(\text{min.})$$

$$K = \frac{V_0}{V_X^2} \quad (\text{Design Requirement})$$

$$R_1 = \frac{\Delta V_X}{200\mu A}$$

$$R_a = \frac{\Delta V_X V_{REF}}{250\mu A \Delta V_X - 200\mu A V_X(\text{max.})}$$

$$R_d = \frac{V_{REF}}{250\mu A}$$

$$R_c = \frac{R_a^2}{R_d}$$

$$R_{cx} = \frac{R_1 R_a}{2 R_d}$$

$$R_0 = \frac{\Delta V_X^2 K}{160\mu A}$$

Figure 11

RC4200

Appendix 1 — System Errors

There are four types of accuracy errors which affect overall system performance. They are:

1. Nonlinearity — Incremental deviation from absolute accuracy. (1)
2. Scaling Error — Linear deviation from absolute accuracy.
3. Output Offset — Constant deviation from absolute accuracy.
4. Feedthrough(2) — Cross-product errors caused by input offsets and external circuit limitations.

The nonlinearity error in the transfer function of the 4200 is $\pm 0.1\%$ max. ($\pm 0.03\%$ max. for 4200A).

$$\text{i.e., } I_3 = \frac{I_1 I_2}{I_4} \pm 0.1\% \text{ F.S. (4)}$$

The other system errors are caused by voltage offsets on the inputs of the 4200 and can be as high as $\pm 3.0\%$ ($\pm 2.0\%$ for 4200A).

$$\text{i.e., } V_0 = \frac{V_X V_Y}{V_Z} \frac{R_0 R_4}{R_1 R_2} \pm 3.0\% \text{ F.S. (3)(4)}$$






Figure 13

65-1871

Errors Caused by Input Offsets



System errors can be greatly reduced by externally trimming the input offset voltages of the 4200. ($\pm 3.0\%$ F.S. for 4200 and $\pm 0.1\%$ for 4200A.)



if; $X_{OS} = X_{OSX}$, $Y_{OS} = Y_{OSY}$, $Z_{OS} = -V_{OSZ}$,


$$\text{then } V_O = \frac{V_X V_Y}{V_Z} \frac{R_0 R_4}{R_1 R_2} \pm 0.3\% \text{ F.S. (3)}$$

Figure 14. 4200 with Input Offset Adjustment

Notes:

1. The input circuits tend to become unstable at $I_1, I_2, I_4 < 50 \mu\text{A}$ and linearity decreases when $I_1, I_2, I_4 > 250 \mu\text{A}$ (e.g., @ $I_1 = I_2 = 500 \mu\text{A}$ nonlinearity error = 0.5%).
2. This section will not deal with feedthrough which is proportional to frequency of operation and caused by stray capacitance and/or bandwidth limitations. (refer to Figure 21.)
3. Not including resistor tolerance or output offset on the op amp.
4. For $50 \mu\text{A} \leq I_1, I_2, I_4 \leq 250 \mu\text{A}$.

Squaring Circuits Offset Adjust



$$10K \leq R_{10}, R_{11} \leq 50K$$

$$R_8, R_{15} = 100\Omega$$

$$R_g, R_{14} = 100\Omega \frac{V_S}{0.1}$$

$$R_5, R_6 = R_1 \parallel R_a$$

$$R_{16} = R_{01} | R_{cl} | R_{cx}$$

Procedure


1. Set both trimmer pots to 0V on the wiper.
 2. Put in a full scale ($\pm V_x$) squarewave on V_x input. Adjust $Z_{os}(R_{10})$ for uniform output.
 3. Connect V_x input to ground. Adjust $V_{os}(R_{11})$ for 0V on V_o output.

Figure 12

RC4200


Divider Circuit Offset Adjustment Procedure

1. Set each trimmer pot to 0V on the wiper.
2. Connect V_X (input) to ground. Put a DC voltage of approximately $1/2 V_Z$ (max.) DC on the V_Z (input) with an AC (squarewave is easiest) voltage of $1/2 V_Z$ (max.) peak-to-peak superimposed on it. Adjust Z_{OS} (R_5) for zero feedthrough. (No AC at V_0)



3. Connect V_X (input) to V_Z (input) and put in the $1/2 V_Z$ (max.) DC with an AC of approximately 20 mV less than V_Z (max.).

Adjust Z_{OS} (R_{13}) for zero feedthrough.




65-1868

4. Return V_X (input) to ground and connect V_Z (max.) DC on V_Z (input). Adjust output V_{OS} (R_{17}) for $V_O = 0V_O$
5. Connect V_X (input) to V_Z (input) and put in V_Z (max.) DC. (The output will equal K.) Decrease the input slowly until the output ($V_0 = K$) deviates beyond the desired accuracy. Adjust Z_{OS} to bring it back into tolerance and return to Step 4. Continue Steps 4 and 5 until V_Z reduces to the lowest value desired.

Note: As the input to V_X and V_Z gets closer to zero (an illegal state) the system noise will predominate so much that an integrating voltmeter will be very helpful.

Square Root Circuit $V_0 = N \sqrt{V_X}$



65-1877

$$\frac{V_X V_{REF}}{R_1 R_b} + \frac{V_{REF}^2}{R_a R_b} + \frac{V_0 V_{REF}}{R_{ao} R_b} = \frac{V_0^2}{R_o R_4} + \frac{V_0 V_{REF}}{R_c R_4} + \frac{V_0 V_{REF}}{R_o R_d} + \frac{V_{REF}^2}{R_c R_d}$$

If $R_a R_b = R_c R_d$ and $R_{ao} R_b R_o R_d + R_{ao} R_b R_c R_4 = R_c R_d R_o R_4$

$$\text{Then } \frac{V_0^2}{R_o R_4} = \frac{V_X V_{REF}}{R_1 R_b} \text{ or } V_0^2 = V_X K \text{ where } K = \frac{V_{REF} R_o R_4}{R_1 R_b}$$

and $V_0 = N \sqrt{V_X}$ where $N = \sqrt{K}$

$0 \leq V_X \leq V_X(\text{max.})$ and $V_0(\text{max.}) = N \sqrt{V_X(\text{max.})}$

$$N = \frac{V_0}{\sqrt{V_X}} \text{ (Design Requirement)}$$

$$R_1 = \frac{V_0(\text{max.})^2}{74 \mu\text{A} N^2}$$

$$R_a = R_d = \frac{V_{REF}}{50 \mu\text{A}}$$

$$R_b = R_c = \frac{V_{REF}}{150 \mu\text{A}}$$

$$R_4 = \frac{V_0(\text{max.})}{50 \mu\text{A}}$$

$$R_{ao} = \frac{V_0(\text{max.})}{125 \mu\text{A}}$$

$$R_o = \frac{V_0(\text{max.})}{225 \mu\text{A}}$$

Figure 9

For More Information, call 1-800-722-7074.

PACKAGING INFORMATION

8 Lead Plastic Dual Inline Package (PDIP) - .300" Body Width

Symbol	Inches		Millimeters		Notes
	Min.	Max.	Min.	Max.	
A	—	.210	—	5.33	
A1	.015	—	.38	—	
A2	.115	.195	2.93	4.95	
B	.014	.022	.36	.56	
B1	.045	.070	1.14	1.78	
C	.008	.015	.20	.38	4
D	.348	.430	8.84	10.92	2
D1	.005	—	.13	—	
E	.300	.325	7.62	8.26	
E1	.240	.280	6.10	7.11	2
e	.100 BSC		2.54 BSC		
eB	—	.430	—	10.92	
L	.115	.160	2.92	4.06	
N		8°		8°	5

- Notes:
- Dimensioning and tolerancing per ANSI Y14.5M-1982.
 - "D" and "E1" do not include mold flashing. Mold flash or protrusions shall not exceed .010 inch (0.25mm).
 - Terminal numbers are for reference only.
 - "C" dimension does not include solder finish thickness.
 - Symbol "N" is the maximum number of terminals.

