



SERVICE MANUAL

MODEL "ROYAL 1000"

ALL TRANSISTOR TRANSOCEANIC

PORTABLE RECEIVER

CHASSIS 9CT40Z2

To the Serviceman

GENERAL

The transistor portable chassis is a conventional super-heterodyne receiver using an individual mixer and oscillator to produce the 455 Kc intermediate frequency. The intermediate frequency amplifiers are conventional. It is necessary to use neutralization in the I.F. amplifier stages as in circuits using a triode tube. The 103-22 diode is used as a detector and AVC voltage source. This diode is part of I.F. Transformer T4. This is then followed by a first audio amplifier and a driver stage for the class B push pull output. The 121-47 output transistors are a matched pair and will be coded with paint dots, red, white, yellow and green. Should one transistor fail it must be replaced with another 121-47 transistor with corresponding color. Do not use 121-47 transistors in pairs unless their color codes are identical.

The iron core slugs of the RF, mixer and oscillator coils have hex-holes through their centers. This will enable the technician to tune the top slug then drop alignment wrench No. 68-32 down through the slug to adjust the slug in the lower coil.

Power Supply — Eight Zenith Z2NL 1½ volt or Standard Flashlight Batteries total 12 volts D.C. Approximate battery life 300 hours. One Zenith Z2NL 1½ volt or Standard Flashlight Battery for the dial light.

Frequency Ranges:

540 to 1600 Kc	11.4 to 12.3 Mc
2 to 4 Mc	14.6 to 15.8 Mc
4 to 9 Mc	17.1 to 18.5 Mc
9.4 to 10.1 Mc	20.7 to 22.5 Mc

Intermediate Frequency: 455 Kc

Power Output Undistorted: 500 Milliwatts

Speaker: 4 inch P.M.

Alnico V, Voice Coil Impedance — 3.2 ohms @ 1000 cycles

Accessory Earphone 39-22 Impedance 15 ohms @ 1000 cycles

RESISTANCE MEASUREMENTS

When making resistance measurements in the circuit, it is most important to remove the transistors in the circuit under test otherwise readings obtained will be incorrect. This is the direct result of a transistor acting as a diode.

When making measurements across an electrolytic capacitor, be certain the ohm meter leads are correctly polarized; also be certain the battery voltage of the meter does not exceed the working voltage of the capacitor. Otherwise damage to the capacitor may result.

VOLTAGE READINGS

It is suggested that a VTVM with an excellent low range scale be used to measure all circuit voltages. All voltages indicated on the accompanying diagrams have been measured under no signal conditions and a carbon battery supply voltage of 12.0 volts. Under these no signal conditions, a check can be made of the batteries. With carbon batteries, the total voltage should be 12.0 volts.

COMPONENT REPLACEMENT

When soldering components at the base of the transistor socket, it is suggested that the transistor be removed to avoid any possibility of excessive heat being transferred through the socket to the transistor. When soldering the low voltage electrolytics and germanium diodes, it is suggested that the wire be held with a pair of long nose pliers while soldering. The long nose pliers will act as a heat sink.

TRANSISTORS

At the present time we do not know of any satisfactory commercially available transistor tester.

If the transistor is suspected of being defective for any other reason than a barrier short, the only reliable check is to substitute a new transistor and then check performance. There is a possibility that if transistors are replaced in the IF or RF circuit, these circuits may need re-alignment as the result of slight differences in transistor characteristics.

SIGNAL TRACING

Past practices used in radio repair commonly known as "Screw driver testing" in which the B+ at the plate of the tube is shorted to ground to check for "clicks" in the speaker, is definitely not recommended. This practice would be comparable to shorting the collector of a transistor to ground which could damage the transistor. Standard point to point signal checking with the proper RF, IF and audio signals, should only be used.

REPAIR EQUIPMENT


The following list of equipment is what we recommend and use for repair of transistor chassis:

1. An RF signal generator supplying frequencies from 455 Kc to 23 Mc.
2. An audio generator or an audio signal source to be used for signal tracing after the diode detector.
3. A VTVM with a good low range voltage scale and a reliable resistance scale.
4. M209B Dazor floating lamp & magnifier or equivalent.
5. A set of optometrist tools—pliers, cutters, picks, etc.
6. A soldering iron with a very fine tip, not to exceed 35 watts.

ALIGNMENT PROCEDURE

OPER.	CONNECT GEN. TO DUMMY ANTENNA	INPUT SIG. BAND FREQUENCY	SET DIAL AT	TRIMMERS	PURPOSE	
1	One turn loop coupled loosely to Broadcast Wavemagnet	455 Kc BC	1600 Kc	T1, T2, T3, T4	Align I.F.	
* 2	One turn loop coupled loosely to Broadcast Wavemagnet	600 Kc BC	600 Kc	Rock gang, Adjust C52B	Alignment of BC at 600 Kc	
3	One Turn Loop Coupled Loosely to Broadcast Wavemagnet	1600 Kc BC	1600 Kc	C52A	Set osc. to scale	
4		REPEAT OPERATIONS 2 & 3				
* 5		600 Kc BC	600 Kc	Rock, adjust L18	Alignment of B.C. mixer at 600 Kc	
6		1400 Kc BC	1400 Kc	C31B	Alignment B.C. mixer	
7		REPEAT OPERATIONS 5 & 6				
8		1400 Kc BC	1400 Kc	C27	Alignment of B.C. ant.	
9	One turn loop coupled loosely to Detachable Wavemagnet	1400 Kc BC	1400 Kc	C28	Place Detachable Wavemagnet in center of a metal framed window & adj. C28 for max	
* 10	3 Feet of Wire Approximately 1 Foot and Parallel from Extended Waverod	2.1 Mc 2-4 Mc	2.1 Mc	Rock L25, L17, L7	Alignment of S.W. osc., mixer & antenna	
11		3.9 Mc 2-4 Mc	3.9 Mc	C26E, C26D, C26B	Alignment of S.W. osc., mixer & antenna	
12		REPEAT OPERATIONS 10 & 11				
* 13		4.25 Mc 4-9 Mc	4.25 Mc	Rock L24, L16, L6	Alignment of Short Wave Oscillator, Mixer and Antenna	
14		8.75 Mc 4-9 Mc	8.75 Mc	C26F, C26C, C26A		
15		REPEAT OPERATIONS 13 & 14				
16		9.7 Mc	31 meters	9.7 Mc		
17		11.8 Mc	25 meters	11.8 Mc		
18		15.2 Mc	19 meters	15.2 Mc		
19		17.8 Mc	16 meters	17.8 Mc		
20		21.6 Mc	13 meters	21.6 Mc		

* NOTE: Rock tuning condenser when making alignment under Operations 2, 5, 10, 13.



CHASSIS PARTS
Chassis 9CT40Z2

PART NO.	DIA. NO.	DESCRIPTION	PRICE
19-322		Coil mtg. clip (23 pt. of S-42118)	.05
19-331		Spring clip (used on S-42118)	.10
22-3 C18	.01 mfd. ceramic disc - 500V	.30	
22-6 C40	470 mmf. ceramic disc - 1KV	.25	
22-11 C11,16, .0033 mfd. ceramic disc - 500V			
44,45 (3 used)			.25
22-17 C17	.001 mfd. ceramic disc - 1KV	.25	
22-18 C41	.0022 mfd. ceramic disc - 500V	.25	
22-1392 C28, 34	25 mmf. ceramic - 500V (2 pt. of S-42118)	.33	
22-1865 C24	5 mmf. ceramic - 500V (pt. of S-42118)	.25	
22-1761 C29, 33	50 mmf. ceramic - 500V (2 pt. S-42118)	.25	
22-2372 C10	22 mmf. ceramic - 500V	.25	
22-2729	.001 mfd. ceramic disc - 25V (2 used)	.25	
22-2883 C43	12 mfd. electrolytic - 50V	1.10	
22-2884 C20, 21	3 mfd. electrolytic - 12V (2 used on S-47501)	1.50	
22-2969	6 section trimmer (2-4 Mc & 4-9 Mc ant., mixer & osc. used on S-43365)	3.00	
22-2972 C30, 30A,B C,D	3 section variable (used on S-42118)	6.00	
22-2979 C35	60 mmf. ceramic - 500V	.30	
22-2981 C39	2700 mmf. mica - 500V (pt. of S-42118)	1.00	
22-2982 C38	4300 mmf. mica (pt. of S-42118)	1.50	
22-2983 C26,27	Trimmer (BC ant. fixed)	.35	
22-2984 C19	10 mfd. electrolytic - 12V	1.00	
22-2985 C15	500 mfd. electrolytic - 12V	2.00	
22-2998 C46	.1 mfd. mylar tubular - 50V	.35	
22-3034 C1,2, 3,5,6, 14,31, 32,42	.05 mfd. ceramic disc - 25V (9 used)	.45	
22-3045 C22,23	.047 mfd. mylar - 50V (2 used on S-47501)	.40	
22-3105 C37A, B	Section trimmer (BC padder)	1.50	
22-3108 C36	100 mmf. ceramic - 500V (pt. of S-42118)	.25	
22-3158 C8,13	7 mmf. ceramic disc - 500V (2 used)	.25	
22-3198 C7,11	2 x .05 mfd. ceramic disc - 25V (2 used)	.50	
44-34	Miniature jack - headphone jack (used on S-47501)	.90	
54-139	3/8-32 x 9/16 hex. palnut (1 mts. ea. 85-591, 63-4623 & 4624)	.03	
54-142	5-40 x 1/4 x 3/32 hex. nut (2 used on 85-591)	.03	
54-345	1/4-32 x 3/8 hex. nut - brass (mts. 44-34)	.03	
54-421	Socket retaining nut (1 used on ea. 78-1063 & 1096)	.03	
57-2385	Sw. mtg. plate (used on S-43365)	.20	
58-235	3 prong plug (battery connector)	.15	
59-330	Dial pointer	.50	
61-137	Idle pulley (3 used)	.10	
63-1740	82 ohm 1/2W ins. 10%	.17	
63-1743	100 ohm 1/2W ins. 10%	.17	
63-1744	100 ohm 1/2W ins. 20%	.17	
63-1761	270 ohm 1/2W ins. 10%	.17	
63-1771	470 ohm 1/2W ins. 10%	.17	
63-1772	470 ohm 1/2W ins. 20%	.17	
63-1775	560 ohm 1/2W ins. 10%	.17	
63-1779	680 ohm 1/2W ins. 20%	.17	
63-1782	820 ohm 1/2W ins. 10% (4 used)	.17	
63-1786	1000 ohm 1/2W ins. 20% (4 used)	.17	
63-1793	1500 ohm 1/2W ins. 20% (2 used)	.17	
63-1796	1800 ohm 1/2W ins. 10%	.17	
63-1800	2200 ohm 1/2W ins. 20% (2 used)	.17	
63-1803	2700 ohm 1/2W ins. 10%	.17	
63-1806	3300 ohm 1/2W ins. 10% (2 used)	.17	
63-1813	4700 ohm 1/2W ins. 10%	.17	
63-1814	4700 ohm 1/2W ins. 20%	.17	
63-1817	5600 ohm 1/2W ins. 10%	.17	
63-1824	8200 ohm 1/2W ins. 10%	.17	
63-1827	10 K ohm 1/2W ins. 10% (2 used)	.17	
63-1828	10 K ohm 1/2W ins. 20%	.17	
63-1834	15 K ohm 1/2W ins. 10%	.17	
63-1848	33 K ohm 1/2W ins. 10%	.17	
63-1852	39 K ohm 1/2W ins. 10%	.17	
63-1862	68 K ohm 1/2W ins. 10%	.17	
63-1875	150 K ohm 1/2W ins. 5%	.34	
63-1880	180 K ohm 1/2W ins. 10%	.17	
63-1898	470 K ohm 1/2W ins. 20%	.17	
63-1904	680 K ohm 1/2W ins. 10%	.17	
63-1912	1 megohm 1/2W ins. 20%	.17	
63-1933	3.3 megohm 1/2W ins. 20%	.17	
63-3392	1500 ohm 1/10W ins. 10%	.17	
63-3663	Thermistor	1.10	
63-4537	6.8 ohm 1/2W ins. 20% (2 used)	.17	
63-4823	Vol. control & Sw. (used on S-47501)	2.05	
63-4624	Tone control (used on S-47501)	1.40	
68-32	Adjusting wrench	.60	
78-644	Connector socket - phono	.15	
78-1063	Transistor socket - 3 contact (6 used)	.35	
78-1096	Transistor socket - 4 contact (3 used)	.35	
78-1097	Wavemagnet socket	.25	
80-402	Drive cord tension spring	.04	
80-1180	Drive cord tension spring	.35	
80-1189	Drive cord tension spring	.15	
80-1230	Spring (cable retaining)	.30	
83-2145	5 lug terminal strip	.10	
83-2827	2 lug terminal strip (2 used)	.05	

CHASSIS PARTS
Chassis 9CT40Z2

PART NO.	DIA. NO.	DESCRIPTION	PRICE
83-2641		5 lug terminal strip	.10
83-2673		6 lug terminal strip	.10
83-2770		7 lug terminal strip - grip type (pt. of S-42112)	.20
83-2822		Ant. terminal strip (pt. of S-42112)	.50
85-495		Radio - phono - switch D.P.D.T.	5.18
85-591		Band switch (pt. of S-42118)	9.00
86-199		Terminal (pt. of S-43365)	.03
86-237		Connector terminal (1 pt. of ea. S-21997 & 21999)	.03
86-308		Terminal	.03
93-968		Lockwasher (2 used on 85-591)	.03
93-1043		Spring washer (used on S-42149)	.10
94-334		Capacitor mtg. bushing (3 mt. 22-2972)	.03
95-1563		1st I.F. transformer (used on S-42112)	2.50
95-1564		2nd I.F. primary transformer	2.50
95-1565		2nd I.F. secondary transformer	2.50
95-1683		Output transformer	4.50
95-1684		Driver transformer	5.00
100-218		Dial light lamp (2 used on S-42148)	.15
103-22		Crystal diode	.75
113-8		6-32 x 1/4 x 1/4 hex. hd. mach. screw lockwasher att. (2 used)	.03
113-9		8-32 x 1/4 x 1/4 hex. hd. mach. screw - lockwasher att. (2 used) on S-47501)	.03
113-13		6-32 x 7/16 x 1/4 hex. hd. mach. screw - lockwasher att. (3 used on 22-2972)	.03
114-193		8-32 x 3/16 x 1/4 hex. hd. self - tap - screw (4 mt. S-43365, 2 used on 57-2385, 3 on 85-591 & 2 mt. R.F. shelf)	.03
114-442		8-32 x 5/16 hex. hd. self - tap - screw flat washer att. (used on 80-1230)	.03
114-444		8-32 x 3/8 hex. hd. mach. screw flat washer att. (used on 80-1230)	.05
114-456		8-32 x 1/4 hex. hd. mach. screw - flat washer att. (2 used on S-43365)	.03
114-571		4-24 x 3/16 x 3/16 hex. slot hd. self tap screw (2 mt. S-42148)	.03
121-44		Transistor - R.F.	5.00
121-46		Transistor - driver	
121-47		Transistor - output (2 used)	5.90
121-48		Transistor - oscillator	5.00
121-49		Transistor - mixer	5.00
121-64		Transistor - audio	2.15
121-73		Transistor - 1st I.F.	2.50
121-74		Transistor - 2nd I.F.	2.50
125-94		Rubber grommet (3 used on S-43365)	.03
126-857		Coil shield	.05
126-887		Coil shield	.10
126-888		Coil shield	.05
126-899		Coil shield	.10
149-86		Iron core (pt. of S-42080)	.10
149-211		Iron core (1 pt. of ea. S-42082, 42083, 42084, 42085, 42086, 42087, 42088, 42089, 42090, 42091, 42092, 42093, 42094, 42095, 42096, 42097, 42098, 42099, 42100, 42101, 42102, 42103 & 43433)	.10
188-149		Retaining ring (1 used on ea. S-41768 & 41779)	.03
199-241		Paper sleeve	.03
S-17638		Drive cord & eyelet assem. - tuning	.10
S-21997		Terminal & wire assem.	.15
S-21999		Terminal & wire assem. (used on S-47501)	.15
S-41768		Dual pulley (used on S-43365)	.50
S-41779		Tuning shaft & pulley assem. (used on S-43365)	.80
S-42080		Ant. loading coil	.60
S-42082		Osc. coil (2-4 Mc. - pt. of S-42118)	.60
S-42083		Osc. coil (4-9 Mc. - pt. of S-42118)	.60
S-42084		Osc. coil (31M - pt. of S-42118)	.60
S-42085		Osc. coil (25M - pt. of S-42118)	.60
S-42086		Osc. coil (19M - pt. of S-42118)	.60
S-42087		Osc. coil (16M - pt. of S-42118)	.60
S-42088		Osc. coil (13M - pt. of S-42118)	.60
S-42089		Ant. coil (2-4 Mc. - pt. of S-42118)	.60
S-42090		Ant. coil (4-9 Mc. - pt. of S-42118)	.60
S-42091		Ant. coil (31M - pt. of S-42118)	.60
S-42092		Ant. coil (25M - pt. of S-42118)	.60
S-42093		Ant. coil (19M - pt. of S-42118)	.60
S-42094		Ant. coil (16M - pt. of S-42118)	.60
S-42095		Ant. coil (13M - pt. of S-42118)	.60
S-42096		Mixer coil (BC - pt. of S-42118)	.60
S-42097		Mixer coil (2-4 Mc. - pt. of S-42118)	.60
S-42098			

CHASSIS PARTS
Chassis 9CT4022

PART NO.	DIA. NO.	DESCRIPTION	PRICE
S-42148		Dial light socket & wire assem. (used on S-42149)	.125
S-42149		Dial drum	5.00
S-42163		Drive cord & eyelet assem. pointer	.20
S-42653		Drive cord, eyelet & spring assem.	.35
S-42723		Elastic cord & staple assem.	.10
S-43258		3rd I.F. transformer & diode assem.	6.00
S-43365		R.F. housing, pulley & stud assem. (mts. S-42118)	2.00
S-43433		Osc. coil (BC - pt. of S-42118)	.60
S-43623		Pulley & bracket assem. (used on S-43365)	.80
S-43686		Coil mtg. bracket (pt. of S-42118)	.50
S-47501		Control mtg. bracket, sw. & strip assem.	

CABINET PARTS

Model Royal 1000 D



PART NO.	DIA. NO.	DESCRIPTION	PRICE
Z-2NL		1.5 V. "A" battery "D" (use 9)	
12-2463		Rear door latch (pt. of S-48168)	.25
12-2604		Support bracket	.95
15-108		Socket cap (pt. of S-48171)	.10
15-191		Plug cap (used on 58-233)	.20
16-1362		Packing carton	
24-1001		Battery case cover	
27-257		Paper disc (4 used)	.03
36-205		Handle - bottom section (mts. S-42207)	1.25
43-311		Wavemagnet housing - fixed (used on S-42184)	.75
46-1809		Tuning knob	2.00
46-1810		Release knob (used on S-42183)	1.25
46-1811		Tone control knob	.50
46-1812		Ant. knob (pt. of S-42207)	.25
46-1825		Selector knob (Band sw.)	1.25
46-1893		Vol. control knob	.50
49-829		4" PM speaker	8.00
54-12		6-32 x 1/4 x 3/32 hex. nut (3 mt. ea. 57-2372 & 2373)	.03
54-444		Speed nut - tinnerman (9 mt. 192-236)	.03
54-445		Speed nut - tinnerman (1 used on ea. 114-87)	.05
54-455		Speed nut - tinnerman (4 used on 57-2389)	.03
54-467		Speed nut - tinnerman (12 used)	.03
57-1725		Emblem plate (used on log chart door)	.25
57-2208		Emblem plate (used on 138-148)	.25
57-2371		Cabinet top plate (mts. 43-311)	5.25
57-2372		End plate - left	8.00
57-2373		End plate - right	8.00
57-2379		Trim plate (band selector - used on 57-2373)	1.25
57-2380		Trim plate (used on 57-2372)	1.25
57-2386		Hinge plate (1 used on ea. 57-2372 & 2373)	.25
57-2389		Escutcheon plate (used on 138-148)	3.75
57-2414		Nameplate (Zenith - pt. of S-42190)	.90
57-2415		Band selector indicator plate (used on 46-1825)	1.25
57-2416		Trim plate - tuning	.80
58-233		7 prong connector plug (used on S-42184)	.55
64-710		Brass eyelet (used on S-48168)	.04
64-725		Rivet (2 used on S-44814)	.03
76-923		Release lever shaft	.10
76-954		Ant. pivot hsg. shaft	.15
78-1101		3 contact socket (pt. of S-48171)	.20
80-1168		Spring - rear door latch	.25
80-1176		Selector knob spring (used on 46-1825)	.10
80-1181		Torsion spring (used on S-42206)	.15
80-1228		Spring - handle	.30
83-2489		Rubber strip (3 used on 57-2371)	.03
83-2741		Trim strip (used on 138-148)	.50
83-2742		Support strip (1 used on ea. 57-2372 & 2373)	.25
83-2785		Rubber strip (2 used on S-42183)	.05
83-2865		Spacer strip (5 used)	.03
83-2930		Retaining strip	.03
86-299		Terminal	.03
86-310		Terminal	.05
86-323		Spade terminal (used on S-42206)	.03
93-166		Lockwasher (6 used)	.03
93-565		Steel washer (4 used on 57-2371)	.03
93-1289		Fibre washer (pt. of S-48171)	.03
93-1301		Felt washer (1 used with ea. 54-444)	.03
93-1324		Steel washer	.03
94-957		Selector knob hub (used on 46-1825)	.75
94-985		Spacer bushing (4 pt. of S-41850)	.05
110-348		Vinyl material (2 used on end plates)	.30

CABINET PARTS

Model Royal 1000 D

PART NO.	DIA. NO.	DESCRIPTION	PRICE
110-349		Vinyl material (cabinet support brkt.)	1.00
110-350		Vinyl material - lower front door (pt. of S-42190)	.75
110-351		Vinyl material - rear door (pt. of S-48168)	1.30
110-352		Vinyl material - inside top door (pt. of S-44814)	.55
112-535		6-20 x 3/8 Phils. pan hd. self tap screw (4 used)	.03
112-1113		4-40 x 7/32 Phils truss hd. mach. screw (4 used)	.03
112-1123		2-32 x 11/32 Fillister hd. self tap screw (3 used on S-43259)	.03
112-1124		4-24 x 11/32 Fillister hd. self tap screw (4 used on S-43259)	.03
112-1140		8-18 x 1/4 Phils. rd. hd. self tap screw (4 mt. 57-2371)	.04
112-1150		4-40 x 1/4 Phils. rd. hd. mach. screw (2 used on S-42190)	.03
112-1156		4-24 x 1/4 Phils. flat hd. self tap screw (4 pt. of S-42190)	.05
112-1190		5-20 x 3/16 Phils. pan hd. self tap screw (6 pt. of S-48168)	.03
112-1205		2-56 x 3/16 slot pan hd. self tap screw (4 mt. S-42193 & pt. of S-42190)	.03
112-1215		4-24 x 3/8 Phils. Fillister hd. self tap screw (5 used on 83-2741)	.03
112-1225		4-40 x 3/16 Phils. hd. mach. screw (2 used on ea. S-41780) & 41850)	.03
113-95		6-20 x 1/4 x 1/4 hex. hd. self tap screw lock washer att.	.05
114-87		8-18 x 1/2 x 1/4 hex. hd. self tap screw (2 used)	.03
114-572		4-24 x 3/16 x 3/16 hex. hd. self tap screw (1 used on ea. S-41778 & 41780)	.03
114-615		6-20 x 5/16 hex. hd. self tap screw (2 used on 57-2416)	.03
114-616		6-32 x 5/16 x 1/4 hex. hd. mach. screw (3 used on ea. 57-2372 & 2373)	.03
114-620		6-32 x 5/16 x 1/4 hex. hd. mach. screw flatwasher att. (2 used)	.03
117-206		Handle release lever	1.75
138-148		Grille (used on S-41850)	2.00
138-168		Background grille	.60
152-266		Handle support block	.30
166-97		Plastic bumper	
166-105		(4 used on S-41850)	.05
166-106		Rubber bumper (5 used)	.03
188-177		Bumper (2 used)	.03
188-226		Knob clamping ring (used on 46-1809)	.03
S-41778		Retaining ring (pt. of S-48168)	.03
S-41780		Dial crystal	5.00
S-41850		Trim plate gasket	.15
S-42183		Shortwave program list	.15
S-42184		Specifications book	
S-42190		Instruction book	.60
S-42193		Shortwave chart book	2.50
S-42206		Service notes	
S-42207		Spring & stud assem. - R.H. (used on 57-2373)	.30
S-42212		Spring & stud assem. - L.H. (used on 57-2372)	.30
S-42297		Cabinet support bracket	5.00
S-42298		Wavemagnet mtg. strip & latch spring assem. (used with S-42184)	.75
S-42299		WAVEMAGNET	3.50
S-42300		Lower door	
S-42301		Log chart ret. plate & compass disc assem. (pt. of S-42190)	4.50
S-42302		Ant. pivot hsg., sleeve & shaft assem. (used with S-42207)	2.50
S-42303		Telescopic antenna	5.50
S-42304		WAVEMAGNET (mobile)	7.50
S-42305		22-2983 trimmer (used on S-42297)	.35
S-42306		83-2785 Rubber strip (2 used)	.05
S-42307		93-1289 Fibre washer (pt. of S-42298)	.03
S-42308		112-850 6-20 x 3/8 Phils. pan hd. Screw (2 used)	.05
S-42309		S-42297 WAVEMAGNET winding	3.00
S-42310		S-42298 cable plug	1.75
S-42311		S-42329 cover & suction cup assem.	1.25
S-42312		S-42330 housing & stud assem.	1.00
S-42313		Handle & pin assem.	1.00
S-42314		Support brkt., trim & vinyl assem.	8.50
S-44814		Top door, trim strip & vinyl assem.	6.50
S-48168		Rear door & bushing assem.	
S-48171		Battery housing, contact & wire assem.	

All prices shown are suggested retail prices
which include Federal Manufacturers' Excise
Tax where applicable and are
subject to change without notice.



Zenith Radio Corporation




4001 Dickens Ave Chicago 30 Ill

**I2I-49
MIXER**

**I2I-48
OSC.**

**I2I-73
1ST I.F.**

**I2I-74
2ND I.F.**



C27
EXTENDED
LOOP

121-44
R.F.

